



Quick Guide



Quick Guide

TouchScale / K-Scale

facilitate interaction between the user and the scale, taking advantage of the visual power of the 15-inch screens and intuitively showing the multiple possibilities of this weighing equipment.

The application will provide you the information and ability to immediately edit the database of products, sales, inventory, listings, the marketing tools integrated into your scales such as playlists, videos and images or tracking loyalty points for customers, among others.





Thanks to the ease of access to information on the scale, the application is characterized by attractive and simple menus and submenus, which allow you to program and configure this powerful tool intuitively.

This quick guide will be useful to know the different functions that the application makes available to you, as well as the different levels of information of the scale with which you can familiarize in a simple and fast way.



MENU STRUCTURE

Quick Guide

TOTALS		Reports Sales reports Billings Labeling reports CSV Export Lists selector Ticket export	Deleting Clear tickets Clear daily tickets Clear packet labels Clear self service labels Clear stock and inventory table Clear shop order			
PROGRAM		Program Counters Families of items Items Items price Price rates VATs	Other options Vendors Customers Customer order Sections of items PLU Keys Codified tares Methods of payment Quick sale keys	Barcode EAN13 Code128 QR EAN128	Stock Stock control Inventory Shop Order	Traceability Bovine Extended generic Nutrition cards Quality levels Ticket marks
CONFIGURATION		Settings Scale settings Numbering Working mode maintenance Working settings Loyalty points	Automation Scheduler Update application Scripts Appereance Appereance Colors Sound Language Date and time	Advertising / Texts Company identification & text Advertising Advertisement playlists Database Save backup Reset backup Restore backup	Devices Printers Automatic turn Automatic cash Payment card Users Users Default users selection User switch...	Weight configuration Weight calibration Weight configuration Weight verification Scale serial number
SCALE NETWORK		Scale network Ethernet Join to network Own scale network Copy database Make / rename server Unjoin from network Explore				

TOTALS



Reports

Sales reports
Billings
Labeling reports
CSV Export
Lists selector
Ticket export

Deleting

Clear tickets
Clear daily tickets
Clear packet labels
Clear self service labels
Clear stock and inventory table
Clear shop order

PROGRAM




Program
Counters
Families of items
Items
Items price
Price rates
VATs

Barcode
EAN13
Code128
QR
EAN128

Traceability
Bovine
Extended generic
Nutrition cards
Quality levels
Ticket marks

Otras opciones
Vendors
Customers
Customer order
Sections of items
PLU keys
Codified items
Methods of payment
Quick sale keys

Stock
Stock control
Inventory
Shop Order



CONFIGURATION



Settings

Scale settings
Numbering
Working mode maintenance
Working settings
Loyalty points

Appereance

Appereance
Colors
Sound
language
Date and time

Database

Save backup
Reset backup
Restore backup

Automation

Scheduler
Update application
Scripts

Users

Users
Default users selection
User switch...

Weight configuration

Weight calibration
Weight configuration
Weight verification
Scale serial number

Devices

Printers
Automatic turn
Automatic cash
Payment card

Textos identificativos
Textos identificativos
Publicidad
Playlists



SCALE NETWORK



Scale network

Ethernet

Join to network

Own scale network

Copy database

Make / rename server

Unjoin from network

Explore

Scale
information

Date and Time

HOME



Exit from Menu

Usual functions

Teamviewer

Encase

Quick guide pdf

User switch

Tares / Scripts

Wizard

Home

Totals

Program

Configuration

Scale network

Turn off



WIZARD



It allows to follow the most usual steps in the configuration of a single scale or scales network.

Set-up a single scale un 5 steps:

1. Program the number and counters name.
2. Program the families.
3. Program the items indicating which family it belongs to.
4. Add the families to the counter and select their order on the screen.
5. Type information about the company.

Set-up a scales network in 4 steps:

1. Setup the scale number in the network and the counter to which it belongs.
2. Configure the scale IP address in network.
3. Create the server name of the scales network.
4. In client scale select the scales network that we are going to connect.



MADRID

C/Punto Net, 3
Parque TecnológicoTECNOALCALÁ
28805 Alcalá de Henares Madrid
Telf. +34 91 830 46 16
Fax. +34 91 830 58 64
infomad@grupoepelsa.com

BARCELONA / Berga

Sant Bartomeu, 108-109
Pol.Ind. La Validan
08600 Berga (Barcelona)
Telf.. +34 93 822 13 33
Fax. +34 93 821 22 34
infobrg@grupoepelsa.com

BARCELONA / El Papiol

Polígono Industrial El Canyet, Nave 7D
08754 – El Papiol (Barcelona)
Telf.. +34 93 654 62 12
Fax. +34 93 654 54 53
infobcn@grupoepelsa.com

SEVILLA

Pol. Industrial La Red
Calle 25 Nave 16
41500 Alcala de Guadaira (Sevilla).
Telf. +95 563 07 09
infomad@grupoepelsa.com

FRANCE

EXA – Pesage Electronique
4 rue Rémora.
Zone d'Activités Rémora
33170 Gradignan
Tél :+33 556 757 780
Fax : +33 587 720 012
info@exa-france.com



http://www.grupoepelsa.com/documentacion/manuales/User_Manual_KScale_TouchScale_EN.pdf